
FUELSEP CORE CREDIT

FUELSEPS require no maintenance, but should be replaced every 5 years.

FUELSEPS that were first installed in 1998 are now approaching the end of their 5 year effective life. You can now return your old unit for a core credit;

- \$75.00 for a WF3500 or WF5000.
- \$ 150.00 credit for a WF7500 or WF9000 unit.


(Core credits will only be issued in conjunction with NEW same unit/size Fuelsep purchase. Credit is only issued after full payment for new units has been received, and retired units are returned to Walker).



WALKER ENGINEERING

FUELSEP INSTALLATION SCHEMATIC

SINGLE FUELSEP APPLICATIONS



- 1. CLOSE ALL FUEL FITTINGS BEFORE THIS OPERATION.
- 2. HOLD THE END CAP AND NOT THE BARREL WHEN TIGHTENING FITTINGS.
- 3. ALWAYS INSTALL THE FUELSEP WITH THE OUTLET HIGHER THAN THE INLET NOTING FLOW DIRECTION (VERTICAL IS OPTIMUM).
- 4. MOUNT A MINIMUM OF 8" AWAY FROM ANY HEAT OR ELECTRICAL SOURCES.
- 5. ALWAYS USE APPROVED FUEL LINE (COAST GUARD).
- 6. APPLY SEALANT TO ALL THREADS (DO NOT USE TEFLON TAPE).
- 7. AFTER INSTALLATION INSPECT ALL CONNECTIONS FOR LEAKS.